Panasonic Broadcast Mechanical Parts List

Model No.: AJ-HPX3000G/MC

Note:

1. *Be sure to make your orders of replacement parts according to this list.
2. Unless otherwise specified, all resistors are in OHMS, K=1,000 OHMS, all capacitors are in MICROFARADS (μF), P=μμF.
3. The P.C.Board unit marked with "■" shown below the main assembled parts.
4. The parts marked with Ⓔ on the exploded view show the electric parts.
4. IMPORTANT SAFETY NOTICE
   Components identified with the mark ⚠ have the special characteristics for safety,When replacing any of these components, use only the sametype.
6. The marking (RTL) indicates the retention time is limited for this item.
   After the discontinuation of this assembly in production, it will no longer be available.
6. "M" in Remark column indicates needed in the periodical maintenance.

CONTENTS

CASING & FRAME PARTS ASSEMBLY OVERALL SECTION (1) MPL-1
OVERALL SECTION (2) MPL-3
CAMERA PARTS ASSEMBLY(1) MPL-5
CAMERA PARTS ASSEMBLY(2) MPL-7
CAMERA PARTS ASSEMBLY(3) MPL-9
TOP CASE & HANDLE PARTS ASSEMBLY MPL-11
SIDE CASE (R) PARTS ASSEMBLY MPL-13
CARD GUIDE PARTS ASSEMBLY MPL-15
REAR JACK PARTS ASSEMBLY MPL-17
BACK CASE PARTS ASSEMBLY MPL-19
LCD PARTS ASSEMBLY MPL-21
PACKING PARTS ASSEMBLY MPL-23

CASING & FRAME PARTS ASSEMBLY
OVERALL SECTION (1)

Components identified with the mark⚠have the special characteristics for safety.
When replacing any of these components, use only the same type.



OVERALL SECTION (1)

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYK2B02	BOTTOM CASE U	1	
2	VMP4853	LENS CONNECTOR PLATE	1	
3	VYQ4196	FOOT BASE U	1	
4	VKC0560	HINGE	1	
5	VJF1559	CLAMPER	1	
⚠ 6	VEE1C95	LENS CABLE	1	
7	VSC5875	MIC SHEILD CASE	1	
8	VMP8764	PB GUIDE ANGLE BOTTOM	1	
9	VGQ8103	PB GUIDE 2	1	
10	VEE0Z86	FRONT MIC CABLE	1	
11	VMT0779	GASKET	1	
12	VLP0123	FERRITE CORE	2	J0KG00000001
13	K1TZB9A00031	COAXIAL CABLE (BLACK)	1	
14	K1TZB9A00052	COAXIAL CABLE (RED)	1	
101	XWE26FJK	WASHER	2	
102	XYN26+A8FJK	SCREW	2	
103	XSS3+8FJK	SCREW	4	
104	XTN3+10JFJK	SCREW	2	
105	XYN26+J6FJ	SCREW	11	
106	VHD1774	SCREW	1	
107	XSB3+8FJK	SCREW	3	
E16	VEP84406A	REAR AUDIO P.C.BOARD	1	
E17	VEP80C55B	STEREO MIC P.C.BOARD	1	

OVERALL SECTION (2)

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

* The part number of card holder is written in Electric Parts List of each P.C.Board.



OVERALL SECTION (2)

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VMP8767	RECEIVER BOX	1	
2	VYF3042	RECEIVER COVER U	1	
3	VEE1B91	RECEIVER CABLE	1	
4	VWJ16G8100L0	FFC	1	
5	VWJ40G7145L0	FFC	1	
6	VWJ30G7125L0	FFC	1	
7	VEE0Z89	L SIDE CABLE	1	
8	VWJ40H2210L0	FFC	2	
9	VWJ30G6060L0	FFC	1	
10	VEE1A00	L SIDE LED CABLE	1	
⚠ 11	VEE1C61	USB CABLE	1	
⚠ 12	VEE1D52	USB WIRE CABLE U	1	
13	VGK3027	LAN CARD BASE	1	
14	VJF1535	COATING CLIP	2	
15	VJF1557	CLAMPER	1	
16	VWJ50G6060L0	FFC	1	
17	VGQ9384	CONDUCTIVE TAPE	1	
18	VYP9238	SIDE L U	1	
19	VMG1642	GUARD	1	
20	VMG1767	USB CAP	1	
21	VMG1768	BNC CAP(A)	1	
22	VGB0692	P2HD BADGE	1	
23	VGB0625	PANA BADGE	1	
24	VQL1N04	FCC/DOC LABEL	1	
25	VYF3041	LAN COVER U TW	1	
26	JOKD00000101	FERRITE CORE	3	
101	XYN2+F6FJ	SCREW	3	
102	XYN2+J6FJ	SCREW	6	
103	VHD1774	SCREW	1	
104	XSB3+4FJKT	SCREW	2	
105	XSB2+6FJK	SCREW	2	
106	XYN26+J6FJ	SCREW	14	
107	XSB3+16FJK	SCREW	2	
108	XYN3+J6FJ	SCREW	1	
109	VHD1462	SCREW	2	
E1	VEP81255B	CAM POWER P.C.BOARD	1	
E2	VEP23660B	CAM SYS P.C.BOARD	1	
E3	VEP23671A	CAM DSP1 P.C.BOARD	1	
E4	VEP23659B	CAM DSP2 P.C.BOARD	1	
E5	VEP83673B	SPDSYS MSC P.C.BOARD	1	
E6	VEP86359B	SPD CPU P.C.BOARD	1	
E7	VEP80E17A	SPD CARD1 P.C.BOARD	2	
E8	VEP80E18A	SPD CARD2 P.C.BOARD	1	
E8-1	VEP80C91A	SD CARD SUB P.C.BOARD	1	FOR VEP80E18C
E9	VEP84400B	SPD AUDIO P.C.BOARD	1	
E10	VEP81254B	SPD POWER P.C.BOARD	1	
E18	VEP80D81B	SPD P.C.BOARD	1	
E19	VEP80D83A	USB A CN P.C.BOARD	1	
E21	VEP80E05A	L SIDE BNC P.C.BOARD	1	
E40	VEP83674A	ZENITH P.C.BOARD	1	

CAMERA PARTS ASSEMBLY(1)

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.



CAMERA PARTS ASSEMBLY(1)

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
⚠ 1	VEQ4550	CAMERA U	1	
2	VWJ14G8065L0	FRONT-PULSE FCC	1	
3	VMP8950	OPTICAL BLOCK ANGLE	1	
4	VWJ10G8037L1	SENSOR FFC	1	
5	VSC6018	SHIELD CASE DRIVE	1	
6	VSC5865	SHIELD CASE PULSE	1	
7	VSC6019	SHIELD CASE PREAMP	1	
8	VGUOB21	FILTER KNOB (ND)	1	
9	VEEOX28	CABLE U	1	
10	VEE1D96	FILTER CABLE U (ND/CC)	1	
11	JOKD00000070	FERRITE CORE	2	
12	VLP0123	FERRITE CORE	1	JOKG00000001
⚠ 13	VEE1C94	PREAMP CABLE U	1	
14	JOKD00000101	FERRITE CORE	1	
15	VMT1815	GASKET	2	
16	VMT1821	GASKET	1	
17	VJF1559	CLAMPER	1	
18	VGUOB22	FILTER KNOB (CC)	1	
19	VMT1879	SHIELD CASE CUSHION	1	
20	JOZZZ0000066	ELECTRIC ABSORPTION SHEET	1	
21	VMT1897	SOFT HIGH SHIELD GASKET	1	
101	XQN2+B25FJ	SCREW	2	
107	XQN2+C4FJ	SCREW	2	
109	XXE26W3FP	HEX SCREW	4	
111	XYN26+J5FJ	SCREW	22	
113	XYN3+J6FJ	SCREW	1	
E12	VEP23650B	DRIVE P.C.BOARD	1	
E13	VEP23653B	PULSE P.C.BOARD	1	
E14	VEP23652B	PRE AMP P.C.BOARD	1	

CAMERA PARTS ASSEMBLY(2)



CAMERA PARTS ASSEMBLY(2)

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYQ4132	OPTICAL U	1	
2	VMAOT71	HEAT SINK (R)	1	
3	VMAOT72	HEAT SINK (G)	1	
4	VMAOT73	HEAT SINK (B)	1	
5	VMAOT74	HEAT SINK BASE	1	
6	VXQO948	O.LPF U	1	
7	VDWO582	MOUNT RING	1	
8	VKF2997	MOUNT CAP	1	
9	VMA9630	LENS SUPPORT ANGLE	1	
10	47B710020	MOUNT RING KNOB	1	
11	109A751302	DETECT ROTARY SWITCH	2	
12	110A1116838	POSITION SENSOR U	1	
13	507A57695C1	FILTER HOUSING U	1	
101	XQN2+C4FJ	SCREW	3	
104	XYN3+C6FJ	SCREW	2	
105	XYN26+F6FJ	SCREW	6	
106	XQS2+A4FJK	SCREW	3	
108	XSB3+6FJK	SCREW	4	
109	110M230601Z	SCREW	1	
E11	VEP20B85A	CCD SENSOR P.C.BOARD	1	

CAMERA PARTS ASSEMBLY(3)



CAMERA PARTS ASSEMBLY(3)

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYK2G71	FRONT CASE 1U	1	
2	VJF1256	CABLE CLAMPER	2	
3	VMG0948	EVF RUBBER SHIELD	1	
4	VMC1210	FRONT DOOR SPRING	1	
5	VMP4850	FRONT DOOR ANGLE	1	
6	VMS4088	FRONT DOOR ANGLE PIN	1	
7	VKF2485	FRONT DOOR	1	
8	VMG0832	SHIELD TUBE	1	
9	VXU1620	RUBBER BUTTON ASS'Y	1	
10	VGU9299	MENU BUTTON	1	
11	VGQ7131	BUTTON HOLDER PLATE	1	
12	VMT1432	WATERPROOF CUSHION	2	
13	VGU9861	MENU KNOB	1	
14	VMG1317	MENU WATERPROOF RUBBER	1	
15	VMG1140	RAIN COVER SPONGE	2	
16	VEE0W38	MENU SW CABLE	1	
17	VEE2804	EARTH CABLE	4	
101	XYN2+C4FJ	SCREW	1	
102	XSB2+4FJK	SCREW	2	
103	XXEV2W4FP	SCREW	2	
105	XYN26+J6FJ	SCREW	3	
106	XYN3+J6FJ	SCREW	4	
112	VMX1312	POLY WASHER	2	
E22	VEP80C57D	FRONT SW P.C.BOARD	1	
E23	VEP80C58C	MENU SW P.C.BOARD	1	

TOP CASE & HANDLE PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.



TOP CASE & HANDLE PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
⚠ 1	VYK2K04	TOP CASE U	1	
2	VGM2190	TOP CASE	1	
3	VYQ3866	SLIDER U	1	
4	VGH4698	VF LOCK NAME PLATE U	1	1SET
5	VGM2168	VF BASE	1	
6	VYQ4071	VF RING U	1	
7	VGU9854	SHAFT LOCK KNOB	2	
8	VLP0186	FERRITE CORE	1	J0KE00000027
9	VJF1319	SHOE	1	
10	VEE1C31	EVF CABLE	1	
11	VEE0Z97	GPS WIRE U	1	
12	VLP0123	FERRITE CORE	1	J0KG00000001
⚠ 13	VEE1D45	OPERATE	1	
14	VEE0Z91	HANDLE SW CABLE	1	
15	VSC5660	WL EARTH ANGLE	2	
16	VMT1631	VF CORE CUSION	1	
17	VYQ4070	FAN MOTOR U	1	
18	VMP8762	FAN COVER	1	
19	VSC5953	AD HEAT SINK	1	
20	VSC5954	TOP HEAT SINK	1	
21	VGQ9303	COOLING SHEET	1	
22	VJF1531	CABLE CLAMPER	2	
23	VYF3137	TOP COVER U	1	
24	VYH0375	HANDLE U	1	
25	VGL1113	TALLY COVER	1	
26	VGH4770	REC LABEL	1	
27	VMT1590	HANDLE SPONGE (2)	1	
28	VGU9695	RUBBER BUTTON (B)	1	
29	VGU9214	SLIDE KNOB	1	
30	VMG1460	SLIDE SW RUBBER COVER	1	
31	VMG0955	P4 O-RING	1	
32	VMG0956	P8 O-RING	1	
33	VKF3917	HANDLE COVER	1	
34	VQL1D81	GPS LABEL	1	
35	VMG1710	GPS BLANK CAP	1	
36	VGQ8103	PB GUIDE 2	1	
37	VMP8763	PB GUIDE ANGLE TOP	1	
39	VGQ9355	COOLING SHEET	1	
40	VSC5966	EVF CABLE SHIELD ANGLE	1	
41	VMX3614	FAN SHEET	4	
101	XVE4A25VW	HEX SCREW	2	
102	XXEV26W4FP	HEX SCREW	6	
103	XSS2+4FJK	SCREW	2	
104	VHD1793	HEX SCREW	3	
105	XWA3BFJK	SCREW	3	
106	XSN2+6FJK	SCREW	4	
107	XYN26+F6FJ	SCREW	2	
108	XYN2+F6FN	SCREW	5	
110	XSB4+8FJK	SCREW	2	
111	XSB3+8FJK	SCREW	14	
112	XYN26+J6FJ	SCREW	16	
113	XSB2+6FJK	SCREW	2	
114	XSB4+6FJK	SCREW	2	
E24	VEP80D06A	HANDLE SW P.C.BOARD	1	
E25	VEP80D07A	HANDLE TALLY P.C.BOARD	1	
E27	VEP80E06A	FAN CONNECT P.C.BOARD	1	

SIDE CASE (R) PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.



SIDE CASE (R) PARTS ASSEMBLY (1)

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYP9237	SIDE CASE R 2U	1	
2	VGU8130	SLIDE SW COVER	4	
3	VGH4977	FILTER NAME PLATE	1	
4	VGL1039	LED PANEL LIGHT	1	
5	VGK3031	TOGGLE SW PLATE	1	
6	VMP5578	SLIDE SW ANGLE	1	
7	VMG1096	VR RAIN COVER PACKING	3	
8	VMG1195	SLIDE SW RUBBER	4	
11	VMS7187	LCD LOCK SHAFT	1	
12	VMB3938	MONITOR LOCK SPRING	1	
13	VYF2895	OPERATION PANEL (B)U	1	
14	VGU9675	MONITOR LOCK KNOB	1	
15	VMC1837	SLIDE PLATE SPRING	1	
16	VMP8366	GUIDE PLATE	1	
17	VMG1286	CUSHION RUBBER	2	
18	VMG1506	DOOR CUSHION	1	
19	VGQ8202	MONITOR POP UP	1	
20	VMP8171	POP UP PLATE	1	
21	VMB3996	POP UP SPRING	1	
22	VMP8059	SPEAKER SET ANGLE	1	
23	VGU9301	VR KNOB FRONT	1	
24	VGU9303	VR KNOB	2	
25	VGU9304	OPERATION RUBBER BUTTON	1	
26	VGU8993	OPERATION BUTTON	1	
27	VMG0646	WATERPROOF SW INSULATION SH	4	
28	VGH4680	VR NAME PLATE	2	
29	VGH4948	VF LABEL	1	
30	VMT1494	WATERPROOF CUSHION	4	
⚠ 31	VEE1D47	HEAD PHONE CABLE	1	
32	VEE0W26	HP2 (REAR)	1	
33	VWJ30H2070L0	LCD IF FFC	1	
34	VEE0Z93	TOGGLE CABLE	1	
35	VEE0Z96	SHOT M SW CABLE	2	
36	VEK0K89	SPEAKER U	1	
37	VMT1622	SPEAKER CUSHION	1	
38	VMX0531	CLATCH SPACER	2	
39	VMX3355	SPACER	1	
40	VJF1535	CLAMPER	2	
⚠ 41	VEE1D46	OPEN SW CABLE	1	
42	VYF3135	OPERATION DOOR U	1	
43	VGU0A79	OPERATION BUTTON	1	
44	VLP0123	FERRITE CORE	2	J0KG00000001
45	VGQ1712	ANP BASE	1	
46	VJF1559	CLAMPER	1	
47	VGL1228	LED PANEL LIGHT	3	
48	VMZ3692	LCD FFC SHEET	1	
49	VMT1801	FACE PAD	1	
50	VGQ9385	CONDUCTIVE TAPE	1	
51	VMZ3685	LCD BARRIER A	1	
52	VMZ3754	ELECTRIC CONDUCTION TAPE	1	
101	XTN3+6GFJ	SCREW	1	
102	XYN2+J6FJ	SCREW	2	
103	XYN2+F5FJ	SCREW	3	
104	XQN2+BJ4FJK	SCREW	1	
105	XYN2+C4FJ	SCREW	2	
106	VMX1312	POLY WASHER	4	
107	XYN2+C5FJ	SCREW	2	
108	XYN2+J6FJ	SCREW	19	
109	XQN2+A3FJ	SCREW	2	
110	VHN0382	NYLON NUT	2	
111	XQN2+A2FJK	SCREW	1	
112	XQN2+BJ4FJK	SCREW	2	
113	XTB26+6GFJK	SCREW	8	
114	XYN2+J6FJ	SCREW	5	
E28	VEP80E01B	SPD LCD P.C.BOARD	1	
E29	VEP80D82B	SPD SSW P.C.BOARD	1	
E30	VEP80D11A	POWER SW P.C.BOARD	1	
E31	VEP80E07A	LCD OPEN SW P.C.BOARD	1	
E32	VEP80D09A	TOGGLE P.C.BOARD	1	
E33	VEP80D03A	V MEM SW P.C.BOARD	1	
E34	VEP80C64A	HEADPHONE P.C.BOARD	2	
E35	VEP80D04A	SHOT M SW P.C.BOARD	1	

CARD GUIDE PARTS ASSEMBLY

* The part number of card holder is written in Electric Parts List of each P.C.Board.



CARD GUIDE PARTS ASSEMBLY

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VGQ9664	CARD GUIDE	1	
2	VGH4773	CARD PLATE 1	1	
3	VMT1581	PB HOLD CUSHION (4)	4	
4	VJF1535	COATING CLIP	1	
5	VSC5674	CARD GUIDE HEAT SINK 1	1	
6	VSC5675	CARD GUIDE HEAT SINK 2	1	
7	VMT1882	CARD BRAKE PAD	1	
8	VGH4802	CAD PLATE 2	1	
9	VSC5946	CCD SHIELD PLATE	1	
10	VJF1557	RE-USE CLAMP	1	
11	VSC6026	CARD EARTH A	1	
12	VSC6027	CARD EARTH B	1	
13	VMP8962	CARD EARTH ANGLE A	1	
14	VMP8963	CARD EARTH ANGLE B	1	
101	XYN2+F6FJ	SCREW	12	
102	XYN26+J6FJ	SCREW	8	
E20	VEP80D10A	L SIDE LED P.C.BOARD	1	

REAR JACK PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.



REAR JACK PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VEJ2285	REAR JACK 1U	1	
2	VGU9300	SLIDE SW BUTTON	2	
3	VMG1511	RUBBER CAP C	1	
4	VMG1085	RAIN COVER RUBBER	2	
5	VGL1038	BOTTOM TALLY COVER	1	
6	VEE1B06	CABLE	1	
7	VEE1C30	ECU CABLE U	1	
⚠ 8	VEE1C96	DC OUT CABLE U	1	
9	K1SYYYYA0002	BNC CONNECTOR	1	
10	VEE1B45	1394 CABLE	1	
11	VJF1559	CLAMPER	1	
12	VMG1792	1394 CONNECTOR CAP	1	
13	VYK2B07	BOTTOM COVER U	1	
14	VMP8676	BACK LOCK ANGLE	1	
15	VMT1591	SHOULDER PAD	1	
16	VMG1508	RUBBER CAP	1	
17	VMG1636	XLR CONNECTOR CAP	1	
18	VMG1769	AODIO OUT CONNECTER CAP	1	
101	XYN26+A6FJK	SCREW	4	
102	XSN26+6FC	SCREW	4	
103	XSB2+6FJK	SCREW	2	
104	XSB3+6FJK	SCREW	8	
E37	VEP80C99C	REAR JACK P.C.BOARD	1	
E38	VEP80D49A	DC INPUT P.C.BOARD	1	
E39	VEP80D12H	1394 CN P.C.BOARD	1	

BACK CASE PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.



BACK CASE PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYKOZ63	BACK CASE U	1	
2	VJF1476	BATTERY ADAPTOR B	1	
3	VGF0960	CONNECTOR COVER	1	
4	VGF1058	BACK CASE COVER	1	
5	VMX2606	SPACER	2	
⚠ 6	VJF1347S	ANTON BRACKET	1	
7	VKC0601	HINGE (REAR)	1	
8	VJF1498	TERMINAL HOLDER	1	
9	VJR0696	CONNECTION TERMINAL	2	
10	VJF1559	CLAMPER	1	
11	VHD1774	SCREW	1	
12	VGF1057	BACK BLIND SHEET	1	
13	VEUUR090ACF	CABLE	1	
14	VEUUB090ACF	CABLE	1	
15	VLP0123	FERRITE CORE	1	JOKG00000001
16	VGQ9553	AMP BASE	1	
17	VEE1C28	CABLE	1	
18	VJF1535	CLAMPER	1	
19	VMZ3466	ZOOM FFC SHEET	1	
20	VMZ3750	BACK CASE BARRIER	1	
101	XSN26+6FJK	SCREW	2	
102	XSB3+4FJK	SCREW	2	
103	XSB3+6FJK	SCREW	2	
104	VMX2605	WASHER	2	
105	XYN26+J6FJ	SCREW	2	
E26	VEP80D89B	BATTERY IF P.C.BOARD	1	

LCD PARTS ASSEMBLY



LCD PARTS ASSEMBLY

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VYK2J46	LCD U	1	
2	VGQ8616	HINGE COVER (LOWER)	1	
3	VGQ8775	HINGE COVER (TOP)	1	
4	VXD0510	HINGE	1	
5	VMG1286	CUSHION RUBBER	1	
6	VKW3338	UPPER LCD COVER	1	
7	VGP6152	LCD CASE BOTTOM	1	
8	VMT1717	WATER PROOF PAD	1	
9	VMZ3610	LCD PCB INSULATION SHEET	1	
101	XQN16+B4FJK	SCREW	6	
E36	VEP08346B	MONITOR P.C.BOARD	1	

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks

PACKING PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.



PACKING PARTS ASSEMBLY

Components identified with the mark ⚠ have the special characteristics for safety.
When replacing any of these components, use only the same type.

Ref.No.	Part No.	Part Name & Description	Pcs	Remarks
1	VFC4148	SHOULDER BELT	1	
2	VFB0203	CAMERA ACCESSORY U	1	
⚠ 3	VQT1K82	OPERATING INSTRUCTIONS	1	FOR AJ-HPX3000G
⚠ 3	VQT1K83	OPERATING INSTRUCTIONS	1	FOR AJ-HPX3000MC
⚠ 4	VYQ4184	OPERATING INSTRUCTIONS	1	CD-R FOR AJ-HPX3000G
⚠ 4	VYQ4185	OPERATING INSTRUCTIONS	1	CD-R FOR AJ-HPX3000MC
5	VPG0T77	PACKING CASE	1	
6	VYQ4015	CUSHION U (TOP)	1	
7	VYQ4016	CUSHION U (LOWER)	1	
8	VPF1176	POLYETHYLENE BAG	1	
9	VPK2280	ACCESSORY BOX (A)	1	
10	VPK2298	ACCESSORY BOX (B)	1	
11	VQL1N88	PACKING LABEL	2	FOR AJ-HPX3000G
11	VQL1N96	PACKING LABEL	2	FOR AJ-HPX3000MC
12	VPN1791	PAD	8	FOR AJ-HPX3000MC
13	VPG1D41	PACKING CASE (OUT)	1	FOR AJ-HPX3000MC